gosund

WiFi Smart Plug Instruction
EP2

✓ **2.4G Wi-Fi Ready** 🚫 **5G Wi-Fi Not supported**

Since the device only supports 2.4G Wi-Fi connection, please ensure that the mobile phone and the device are connected under 2.4G Wi-Fi simultaneously.

What's in the Box

1. Wi-Fi Smart Plug
2. User Manual
3. After-sale card
4. Connectivity Guidelines

At a Glance

① ON/OFF Button
② Flame Resistant Material
③ Power Plug
④ Socket Panel

Main Features

Voice Control	APP Control	Scheduled Control	Family Sharing
No Hub Required	Mini Size	Group & Scenes Customization	V0 Fireproof Materials

---

Specification

Model: EP2
Rated Voltage: 230V~50/60Hz
Rated Current: 10A Max.
Wi-Fi frequency: 2.4GHz
Power Output: 2300W Max.
Frequency Range: 2412-2472 MHz
Wi-Fi Max. Transmitting Power: 20 dBm

How to download the Gosund App

Option 1: Search for "Gosund" in the Apple APP Store or Google Play.

Option 2: Scan the QR code below to enter the down load page.

How to Pair with the Gosund App

Note: Support 2.4GHz Wi-Fi only.

1. Open the "Gosund" APP and create your Gosund account.
2. Turn on the plug and put it close to the router when pairing.
3. Press and hold the ON/OFF button for 5 seconds and release it when the plug starts blinking fast to enter the network pairing mode.


You can add a device in two ways.

Option 1. Tap "+" on the upper right corner and select "Auto Scan".

Option 2. Tap "+" on the upper right corner to select "Add Manually", and then select "Power Strip (Wi-Fi)". Follow the App instructions to complete the operation.

How to Connect to Alexa

Note: Support 2.4GHz Wi-Fi only.

1. Make sure your Alexa device is powered on and connected to a Wi-Fi network.

2. Open Amazon Alexa APP and select "skills & Games", as shown in the figure below.

---

3. Click "Search" icon and enter "Gosund" as shown in the following figure.

Search

Keyword or skill name: Gosund

gosund
gosund app plug
gosund skill

---

4. Find "Gosund", click "enable" and contact your Gosund account to enable skill. As shown in the figure below:

Gosund
Rated: Guidance Suggested
ENABLE TO USE
Account linking required

(1)

Link Account
Gosund
(2)

Link Account
The following Apps all support skill. Please select an App to log in:
TuyaSmart
Gosund ✓
Link Now
(3)

---

5. Then the device can be controlled through Alexa.

Link Account
Alexa by Amazon will be able to:
Receive your public profile
Control your devices over internet
Authorize

---

6. Now you can begin your smart home journey.
Operation Video Link:
https://youtu.be/6aY8jhjE0A8

How to Connect Gosund Devices to Google Assistant

Note: Support 2.4GHz Wi-Fi only.

1. Open the Google Assistant APP and login in.
2. Tap your account name of the upper right corner.

Good afternoon! 🔆
Partly cloudy 31°C

📞 Make a phone call   💬 Send a message   ▶ Play a

All your events and reminders, in one place
Allow your Assistant to access your Apple calendar events and reminders
Continue   Not now

Your calendar is clear today

---

3. Click "Devices" to add devices.

Languages — For speaking to your Assistant
Music — Services used to play music
You — Manage your information and personal preferences
Devices — Manage devices that are linked to your Assistant
View less
Assignable reminders — Choose who can send you reminders

---

4. Find "Link a smart home device" and click it.

Add a device
Set up a new device or link a device that works with your Google Assistant

Set up a Bluetooth device
Bluetooth devices that work with your Google Assistant

Link a smart home device
Keep your devices or services in your home that work with your Google Assistant

---

5. Enter "Gosund" to search and click the "Gosund smart".

Add new
Gosund smart

6. Enter your Gosund APP account and password, then tap "Link Now".

---

7. Now you can begin your smart home journey. Operation video link:
https://youtu.be/LgCPRFsFUpE

Reset

Turn on the power, hold the Switch/Pairing for 8 seconds and let go when the socket starts to flash quickly, the reset is successful.

When the socket is In a new network environment, you need to restore the factory settings, and then reconnect to the network.

Warnings and Precautions Important!

- Keep it out of the reach of children and pets.
- Do not use this product in humid environments or outdoors. It's for indoor use only.
- Do not place this product near heating devices, such as microwave ovens, or radiators.
- Protect the product from extreme temperatures, direct sunlight, strong jolts high humidity, moisture, flammable gases, vapors and solvents.
- Do not disassemble, modify, or repair your device, and ask help from the authorized professionals for device malfunction.
- Do not use the device when it is no longer working properly or visibly damaged.
- Do not store the device for extended periods in poor ambient conditions.
- Do not insert your device to another one.
- Never use aggressive detergents such as rubbing alcohol or other chemical solutions because these could damage the casing or even impair the functioning of the product.

Note: The image shown in the manual is indicative only. If there is inconsistency between the image and the actual product, the actual product shall govern.

WEEE Disposal and Recycling Information

All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

🔲 CE EAC ♻ 🚮 RoHS

Made in China

4.02.000.0609 V1.0